


HDD Usage with the Kanguru USB Duplicator

The Kanguru USB Duplicator has external USB HDD support.

Please follow these instructions when duplicating an external USB HDD using the Kanguru USB Duplicator:


1 Power on the Kanguru USB Duplicator.



2 Power your external HDD using the power cord that was included with your hard drive.




AC Adapter




Y-Type USB

3 Follow the diagrams below to connect your external USB hard drive to the duplicator.


3.5" HDD with AC Adapter




2.5" HDD with Y-Type USB Cable



2.5" HDD with Hub



2.5" HDD with Y-Type USB Cable and Hub



If you are still having trouble duplicating your external USB HDD, try the following:

- Use an uninterruptible power supply with the USB Duplicator and USB HDDs to maintain constant electrical voltage.
- Power off the unit, connect the HDDs and then power it back on.
- Check the file system being copied and what copy mode the USB Duplicator is set to (Brief mode is limited on which file systems it can duplicate).