


HDD Usage with the Kanguru USB Duplicator


The Kanguru USB Duplicator has limited external USB HDD support.

Please follow these instructions when duplicating an external USB HDD using the Kanguru USB Duplicator:


1 Power on the Kanguru USB Duplicator.



2 Power your external HDD using the power cord that was included with your hard drive.




AC Adapter




Y-Type USB

3 Turn on the HDD and allow it to completely power on. Once the hard drive is completely powered on, connect the USB data cable to the USB duplicator.
Note: The Master drive should be connected to the top left port before any target drives are connected.


3.5" HDD with AC Adapter



Powered USB hub



2.5" HDD with AC Adapter



2.5" HDD with Y-Type USB Cable

If you are still having trouble duplicating your external USB HDD, try the following:

- Use an uninterruptible power supply with the USB Duplicator and USB HDDs to maintain constant electrical voltage.
- Check that the 'No Check USB Capacity' option in the Setup Menu is enabled.
- Check the file system being copied and what copy mode the USB Duplicator is set to (Brief mode is limited on which file systems it can duplicate).